Routine Maintenance 5.1 Maintenance Schedule Excerpt from "1008 Operating Instructions" 0297 9689 en

In running hours (h) ¹⁾ every every										check			Section
										clean			
once after	10h and								renew				
50-150	daily resp	125	250	500	1000	2000	2500	5000				Job]
	•								•			Oil level 9)	6.1.2/3.1.6
•									•			Engine for leakages	
	•								•			Oil bath- and dry type air cleaners 314)	6.3 / 6.4
•									•			Battery and lead connections	6.7.1
		•	•	•	•	•			•			Cooling system (dep. on engine use) 397)	6.3.1/6.3.2
•		•							•		•	Engine oil (dep. on engine use) ⁵⁾	6.1.1/6.1.2
•			•								•	Oil filter cartridge	6.1.3
•			•								•	Fuel filter cartridge	6.2.1
•				•					•			Valve clearance and rocker arm clearance (readjust if nec.)	6.6.1
					•				•	•		Adjustment of injection nozzle	
•			•						•			V-belts (retension if nec.)	6.5.1
							•				•	Toothed belts 10)	
						•				•		Fuel strainer/Fuel screen	4.2.1
					•					•		Fuel tank	
					•						•	Coolant 6)	6.3.3/6.3.4
	•								•			Coolant level 8)	3.3.3

The specified engine maintenance times are maximum values. Depending on the operating environment, shorter maintenance intervals may be required. Please observe the operating instructions of the equipment manufacturer.

- 1) Max. perm. guide intervals
- Commissioning new and overhauled engines
- 3) Clean if nec.: see Section 6.3
- Renew if nec.
- 5) Oil change intervals: see Section 6.1.1

- 6) Check additive concentration (antifreeze concentration) before frost is imminent, or every two years.
- Radiator fins
- 8) According to engine design
- 9) During run-in period, check 2x daily
- 10) or after at 5 years at the latest.
 Belts shall be changed solely by the service agents responsible for you or bei trained specilist personnel.